



1 Sign up for plan and complete activation steps.

Go to **summitcontrol.com** and follow the steps given in the **Activation Guide**.

2 Install, wire, power on, and test* unit(s). Leave unit(s) powered on for initial setup by Summit Control.

Refer to the **Install Guide**. A professional installer is recommended for installation.

** Only models with keypads can be tested before activation.*

3 Once activated, you may go to your admin dashboard to set up your Ascent unit(s).

Available features vary depending on Ascent model.



NEED HELP

Call (972) 474-6422

Email support@summitcontrol.com

We are available **Mon-Fri / 8am-5pm Central**